

Features

- Remote control of most desk functions
- Palette recall
- Channel control
- Password protection
- Standard Wireless Link (802.11b or better)
- Software upgradable
- Free download
- Command line interface



Overview

The ZerOS Remote is a software application for a handheld Pocket PC, which adds remote control functionality to the Frog 2 and Leap Frog 48/96 consoles. The application integrates directly with the Frog 2 and Leap Frog 48/96 when a network connection is present and enables the use of the front panel buttons and palette buttons.

The ZerOS Remote requires a standard Pocket PC running Windows Pocket PC 2002/2005 or Windows Mobile 5 or 6, and a network connection to the console. This network connection can take the form of a wired network or (with the addition of a wireless switch/router) a wireless network.

One version of software will support both desk types.

Ordering Information

Free software download available from the Zero 88 website www.zero88.com

Frog 2 Features:

- Direct control of Frog 2 keypad
- Direct control of Frog 2 function keys
- Palette buttons from your handheld
- Palette name exchange with the console
- Command line view on handheld (monitor the console from remote areas)

Operation:

The remote shall provide four pages of button access, capable of displaying all the control areas of the front panel of the Frog 2. Tabs at the bottom of the remote window shall provide access to the four palette windows (Colour, Beamshape, Position and Effects). The palette windows shall display the name and contents of the palette, as with the main console.

Leap Frog 48/96 Features:

- Control of Presets, Submasters, Playback.
- MFKs from your handheld
- Palette buttons from your handheld
- Palette name exchange with the console
- Desk Output is also shown

Operation:

The remote shall provide access to the Presets, Submasters, Playback, MFKs and Palettes.

The palette windows shall display the name and contents of the palette, as with the main console.

Desk Output will also be shown, as with the Output window on the main console.

	Voltage	100V	<input checked="" type="checkbox"/>	220 - 240V NON CE	<input checked="" type="checkbox"/>		
		110 - 127V	<input checked="" type="checkbox"/>	277V	<input type="checkbox"/>		
		230V CE	<input checked="" type="checkbox"/>	347V	<input type="checkbox"/>		

This product conforms to one or more of the above standards. Please contact your local Cooper Controls representative for further information.

Zero 88

Cooper Controls Ltd, Usk House, Lakeside Close,
Llantarnam Park, Cwmbran, NP44 3HD, UK.
Tel : +44 (0) 1633 838088 Fax : +44 (0) 1633 867880
E-mail : enquiries@zero88.com web : www.zero88.com